How to Install Your PIPOS Hardware

List of Hardware

May vary depending on what workstation was purchased.

- 1. PIPOS Unit
- 2. Power Supply
- 3. Ethernet Cable

*if you purchased a touchscreen monitor as well

- 1. HDMI Cable
- 2. Monitor
- 3. USB Cable

PIPOS



Power Supply




Ethernet Cable




HDMI Cable



PIPOS Ports









Diagram of how to connect your PIPOS Unit



The modem/switch is where all your network devices plug into, such as Computers and Printers

If you are unsure please call Imagatec on 1300 365 443 for guidance

pipos_mlm_diagram.xlsx

From:

https://wiki.imagatec.com.au/ - Imagatec Wiki

Permanent link:

 $https://wiki.imagatec.com.au/doku.php?id = customer_portal: site_hardware_configuration: install_pipos_hardware_configuration: install_pipos_har$

Last update: 2025/07/14 14:48

