

iPOS CloudPOS Hardware Requirements

Client Devices

A Client “device” connects to the CloudPOS and displays the POS for use by operators.

Each device must be AUTHORISED for access and must use a secure token for authentication, without which, CloudPOS access is unavailable. you can use the following guide to AUTHORISE your devices:

http://wiki.imagatec.com.au/doku.php?id=customer_portal:guides:cloud_pos_setup

Recommended client devices:

- Apple iPad
- Imagatec PIPOS Workstations

Minimum POS terminal requirements:

- Intel Dual-core CPU @ 2Ghz (Intel Celeron and Intel Atom processors not recommended)
- 4GB of RAM
- Windows 10 Pro, Windows 7 Professional, POSReady7. (NO XP, Vista or 'Home' editions)
- Internet Explorer 10.0 (or above)
- Wired network connection
- Rustdesk for remote support

* Please contact Imagatec for access to the iPOS CloudPOS Demo to test if your mobile or POS terminal is capable of running the CloudPOS.

Printing

Printer Requirements

To print from your Cloud POS system you will need a printer with an Ethernet Interface.

To use an Ethernet printer you will need to have a fixed local area network in place for it to connect to.

Compatible Printers

- **Epson TM-82II-i Ethernet Printer**
- **Epson TM82 Ethernet Printer**
- **Epson TM88 Ethernet Printer**

Imagatec PiPOS Print Server

Imagatec's PiPOS Print Server is required to be able to print from your Cloud POS.

It needs to be connected directly to your modem/internet gateway via ethernet.

When the print button is clicked on the client, the PiPOS Print Server tells the correct printer what to print.

Please note: Network cabling is not a service provided by Imagatec and will need to be sought from a licenced cabler or electrician in your area.

From:
<https://wiki.imagatec.com.au/> - Imagatec Wiki

Permanent link:
https://wiki.imagatec.com.au/doku.php?id=customer_portal:site_hardware_configuration:iposcloudpos_requirements&rev=1752468527

Last update: 2025/07/14 14:48

